







\* 4 4 6 1 3 3 8 2 1 \* (1)



This Quick Setup Guide is for overpack package of STR-DH540, SS-FCR3000, and SA-W2500.

Connect and turn on your receiver. For details, refer steps 1 to 3 in the Quick Setup Guide of the receiver. Then, make the following settings.

### 1 Adjust the cut-off frequency of the subwoofer (A)

Turn the CUT OFF FREQ control to the location between ② and ③ as shown in the illustration above.

### 2 Set the phase polarity of the subwoofer (B)

Set the PHASE switch to “REVERSE” (Default setting).

### 3 Adjust the volume level of the subwoofer (C)

Turn the LEVEL control so that you can hear the bass sound. It is recommended to adjust the LEVEL control to the position as shown in the illustration above.

### 4 Set up the receiver and perform Auto Calibration

For details, refer to step 4 in the Quick Setup Guide of the receiver.

### 5 Adjust the front speaker size (D)

Press HOME, then use  $\uparrow/\downarrow/\leftarrow/\rightarrow$  and  $\oplus$  to select “Settings” > “Speaker Settings” > “Manual Setup” > “Size” > “Small”.

### Note

You can also adjust the settings according to your preference.